



Initializing an IP Set

1. Plug power and data connection into the phone.
2. When the Nortel Networks logo appears, press each of the 4 soft keys, starting from left to right.
3. *Manual Cfg*: DHCP: Yes
4. *DHCP*: Partial
5. *S1 IP*: <BCM IP Address>
6. *S1 Port*: 7000
7. *S1 Action*: 1
8. *S1 Retry*: 7
9. *S2 IP*: <BCM IP Address>
10. *S2 Port*: 7000
11. *S2 Action*: 1
12. *S2 Retry Count*: 7
13. *VLAN*: No
14. *Cfg XAS*: No