



Assigning IP Address to Call Pilot

CP Default IP: 192.168.110.10

1. Change the IP address of the laptop to IP in range
Example: 192.168.110.11

- Click on Start/ Settings/ Control Panel
- Click on Network & Dial up connections
- Click on Connection
- Click on Properties
- Click on Networking tab
- Click on Properties
- Click on "Use the following IP address"
- Enter new IP address

2. Open up Web Browser and enter 192.168.110.10

3. Install Wizard will appear

- Enter the new IP address
- Answer all questions
- Press enter

The IP address has now been changed on the Call Pilot. You will have to re-boot in order for the changes to take place.