

































Feature operation

AutoDial			
Store	AutoDial		▶ AutoDial
Use		AutoDial	
Display	Display	AutoDial	
Call Forward			
Activate	Fwd		▶ Fwd
Deactivate	▶ Fwd		
Reinstate	Fwd	▶ Fwd	
View number	Display	▶ Fwd	
Call Pickup			Pickup
Call Waiting			
Answer		▶ CWT	
	(Hold)		
Return to first call			
Conference		Conf	
			▶ Conf
Handsfree			
Activate			
Switch to handset			
Handset to handsfree			
Hold			
Place a call on hold			
	(Hold)		
Return to a held call			
Last Number Redial			
Message			
Ring Again			
Activate	RngAgn		
When notified		▶ RngAgn	
Deactivate	▶ RngAgn		
Transfer		Trans	
			▶ Trans

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the DN key, or press the Handsfree key.

	Replace the handset, or press  to end the call.
	Dial a number.
	Press the line (DN) key.
▶ AutoDial	The ▶ flashes when a feature is being programmed. The ▶ lights when a feature is active.
	Press the Services key.
	Press the Message key.
	Press the Navigation keys.
	Press the Handsfree key.
	Press the Mute (on/off) key.
	Press the Directory key.

Service and Telephone Options menu

Services menu


















(Services)

Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 2002 phones. Consult your system administrator.

Telephone Options menu


Volume adjustment

Ringer	Select			Select	
Handset	Select			Select	
Handsfree	Select			Select	
Headset	Select			Select	
Buzzer	Select			Select	

Contrast adjustment




Language\



Date/Time format



Local DialPad Tone



Ring type



OnHook Default Path



Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 2002, consult the *Nortel IP Phone 2002 User Guide*.

Nortel IP Phone 2002



IP Phone 2002

For Nortel Communication Server 1000

Quick Reference Card



Date: August 2005

Document Release: Standard 4.00

Document Number: NN-10300-039

Copyright © Nortel Networks Limited 2005

All rights reserved.

* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.